

180*180mm
正面

Lalarma Noise
Cancelling Headphone
with Max of 85 dB

EN user manual



Thanks for purchasing a Lalarma product - Cool tech for cool kids with cool parents!
We always use advanced technology of high quality.
All our products are made from Recycled plastic, and we try to be as sustainable as possible. "It is all about the small steps to a better world!"

Wishing you a super experience with one of our cool products!
XX AS, Founder - Lalarma Copenhagen

Before you can start using your new Lalarma product, we must inform you about a few things:



- CAUTION: Read this manual carefully and save for the future.
- Power management: Always turn off the device before cleaning or storing to prevent hazards.
 - Unauthorized disassembly: Avoid disassembling the device without proper authorization to prevent malfunctions and void the warranty.
 - Sunlight and temperature: Keep the device away from direct sunlight and extreme temperatures for optimal performance.
 - Fire and battery safety: Prevent exposure to fire, fumes, and smoke to avoid battery explosions.
 - Liquid and dust: Protect the device from liquids and dusty environments to prevent damage.
 - Physical protection: Avoid dropping or scratching the device to maintain functionality.
 - Manual reference: Read and retain the manual for understanding proper usage and maintenance.

DISCLAIMER
Legal and Void of Warranty - Njord Collect ApS will not be held responsible for injury or damage caused by misuse or failure to follow product guidelines.

In the EU and other European countries with separate collection systems, this symbol on a product or its packaging means it shouldn't be treated as household waste.
Instead, it should be taken to a collection point for recycling electrical and electronic equipment. Proper disposal prevents environmental and health risks and conserves natural resources. For more details, contact your local city office or waste disposal service.



背面



CHARGE
LET'S CONNECT

First Time Pairing

Power On **5** .Press the multi-function button to turn on.A voice prompt 'Power on, pairing' confirms the headphones are on and in pairing mode. The LED Indicator Light **7** will flash WHITE and BLUE ready to pair with your audio device.Go to the Bluetooth settings on your audio device to select 'Lalarma ANC' from the list. Once paired successfully you will hear 'Connected' and the LED Indicator Light **7** will switch off. You can now enjoy your music, video or other entertainment. The headphones will automatically reconnect to the last device they were paired with, confirming 'Connected'. If there is no Bluetooth connection after 5 minutes, the LED Indicator Light **7** will begin to flash BLUE and WHITE for 60 seconds. The headphones will then automatically turn off by confirming with 'Power off' and the LED Indicator Light **7** will flash White once and then switch off.

LET'S PLAY

First Time Pairing

Press and hold the multi-function button **5** to turn on your headphones. Go to the Bluetooth settings on your audio device to select 'Lalarma ANC' from the list. Once paired with your device, you will hear 'Connected'.

Play / Pause Answer / End a call

Short press **5** to Answer / Play, or Pause / End a call. **5**

Volume Up / Down

Short press the Volume Up / Down Buttons **4** / **6** to adjust the volume

Skip / Previous Track

Press and hold the Skip / Previous Track Buttons **4** / **6** to change tracks

Active Noise Cancellation (ANC) On / Off and Transparent Mode

Short press the ANC button **8** to cycle through the following modes:

TRANSPARENT MODE > ANC ON > ANC OFF.

You will hear a voice announcement telling you which mode you are in: 'Transparent On', 'ANC On' or 'ANC Off'. The ANC LED light **7** will glow GREEN while either Transparent mode or ANC mode is being used.

Change the Preset Equalisation (EQ) Settings

Choose from 3 Equalisation (EQ) modes to suit your personal preference. There is no App required.

- Bass boost mode increases the bass sound.
- Voice mode decreases the bass, the high-frequency tones and increases the speech frequencies.
- Music mode returns you to the optimal EQ for music listening.

Power On / Off

Press and hold the multi-function button **5** on / off. You will hear 'Power on / off'.